



## JEM Radio II Quick Start Guide

1. TX/RX Channel Selection:  
Press **CHAN**. Enter **3 digit TX** channel, **3 digit RX** channel. Then press **CHAN** again.
2. Enter Custom RAN:  
Press **RAN**. Enter **2 digit TX RAN**, **2 digit RX RAN**. Then press **RAN** again.
3. Send PLL Tones when on analog channel:  
Press **RAN**. Enter **2 digit TX PLL**, **2 digit RX PLL**. Then press **RAN** again.
4. Change to Home Channel:  
Press **HOME** enter **home channel number** then press **HOME** again.
5. PTT: Press and hold **PTT** (Push-To-Talk) button to activate microphone and begin transmission. Let go to end transmission.
6. View Previous Text Message:  
Press **MENU > 1 GENERAL > 3 SCROLL TEXT > MENU**.
7. View All Text Messages (up to 10):  
Press **MENU > 1 GENERAL > 3 SCROLL TEXT > Volume Up/Down to change message number to 0 > MENU**. All messages will scroll across display in chronological order, starting with newest.
8. Quickly Switch Back to Previous Channel/RAN:  
Press **HOME** followed by the # key.
9. Adjust Display Brightness:  
Press **MENU > 5 Display > 1 Brightness > Volume Up/Down**.
10. Adjust Volume:  
Press **Up Arrow** on **VOL** button to increase volume. Press **Down Arrow** on **VOL** button to decrease volume.
11. Send DTMF tones:  
Press number buttons **0 through 9** to transmit DTMF tones.
12. Adjust Squelch:  
Press **MENU > 1 GENERAL > 1 SQUELCH > Volume Up/Down**.